



PO BOX 6603, LOS OSOS, CA 93412 805 528-AERO (2376) 528-2377 FAX

Aileron Trim Removal Tips

Assembly is attached to housing with three #8-32, flat head screws. Access to these screws can be gained by unscrewing the two halves of the trimmer knob. Since it is reverse threaded, one must **tighten** the two knob halves to loosen it. The parting line is between the knurl on the knob's outside diameter. Early version knobs have a series of dimples instead of knurling. Do NOT remove the retainer clip holding the plastic bezel.